



City of Lemoore
 711 W. Cinnamon Drive
 Lemoore, Ca 93245
 559-924-6744 ext 730 Phone
 559-924-6708 Fax

Owner Name _____
Property Address _____
Contractor/Owner Name _____
Phone Number _____
Work Description _____
Valuation \$ _____

ATTIC VENTILATION WORKSHEET

Step 1

Determine Total Square Feet of Attic Floor Space ("Enclosed" Attic Space)

House: Length of Attic _____ X Width of Attic _____ =(a¹) _____ Square feet of Attic Space
(Repeat process for all attic areas)

Garage: Length of Attic _____ X Width of Attic _____ =(a²) _____ Square feet of Attic Space
(Repeat process for all attic areas)

Unenclosed/No Attic Space Area (b) = _____ Square Feet

Net Ventable Attic Space (c) = _____ Square Feet (a)-(b)=(c)

Step 2

If your attic currently has ducting, please check this box

Calculating Ventilation Requirements

(c) _____ /150 = (d) _____ Square feet in code required ventilation or / 300 if no ducts in attic

Step 3

Calculating Square Feet to Square Inches

(d) _____ *144 = (e) _____ Square inches in code required ventilation

Step 4

Determine High & Low Ventilation Requirements

(e) _____ /2 (high & low ventilation = (f) _____ Square inches in code required ventilation (high & low)

Step 5

EXISTING LOW (# vents & type) _____ **vents (at** _____ **Square inches each)** _____

Provided Low (# vents & type) _____ vents (at _____ Square inches each) **(verify with manufacturer)** _____

Provided Low (# vents & type) _____ vents (at _____ Square inches each) **(verify with manufacturer)** _____

TOTAL LOW= _____

EXISTING HIGH (# vents & type) _____ **vents (at** _____ **Square inches each)** _____

Provided High (# vents & type) _____ vents (at _____ Square inches each) **(verify with manufacturer)** _____

Provided High (# vents & type) _____ vents (at _____ Square inches each) **(verify with manufacturer)** _____

TOTAL HIGH= _____

Total Ventilation provided= _____ Square Inches

Example:

Step 1/Attic Area 60ft X 20ft = (a) 1200 Sq ft (b) = 0 (a) 1200 – (b) 0 = (c) 1200

Step 2/Ventilation Calculation: (c) 1200/150 = (d) 8 Sq f

Step 3/Convert to Square Inches: (d) 8 X 144 = (e) 1152 Sq inches

Step 4/High and Low Vent Area Req'mts: (e) 1152/2 = (f) 576 Sq inches

Step 5

Provided Low (intake) 12 soffit vents (576/48 Square inches each) **(verify with vent manufacturer)**

Provided High (intake) 12 dormer vents (576/48 Square inches each) **(verify with vent manufacturer)**

Total Ventilation provided = 1152 Square inches